
terminal connection
window motor right door
plug board - 2 pole
window switch 6
terminal connection
window motor right rear
window up relay
window down relay
window switch 3
window switch 4
window down relay
window up relay
window down relay
window switch 1
window switch 2
window up relay
window up relay
window down relay
window motor left door
terminal connection
plug board - 2 pole
window switch 5
terminal connection
window motor left rear
remove this portion of the existing wiring
load shedding relay
20a fuse
plug board
battery
ignition switch
1
2
3
4
5
6
7
8
9
10